


# PWR14 Connection Data



1. Positive supply solely for test
2. Signal Input (twisted pair to input socket)
3. Signal Ground (twisted pair to input socket)
4. Power Ground direct to zero volts on PSU
5. 12V trigger negative (optional)
6. 12v trigger positive (optional)
7. Speaker output
8. Negative supply solely for test

The same pads exist on the reverse side of the PCB linked by the vias, take care to order them correctly.

## Power Supply Wiring PWR14

